CONNECTING COMPONENTS

Speaker Terminals — Use the color-coded wires (supplied) to connect each speaker to the appropriate terminal. For example, use the brown and black speaker wires to attach the subwoofer to the SUB WOOFER terminals. Note: Be sure to connect the solid black wire to the black terminals, and the black-and-color striped wire to the color terminals.

DIGITAL OUT — If you have a digital audio device such as a MD or DAT recorder, use Toslink cable to connect it here

Connect AM and FM antennas here

To your TV's video IN if your TV has an S-Video input

To an analog auxiliary device's OUT audio jacks

Connect a second subwoofer here

To your TV's analog video IN jack

SAT IN — To your satellite receiver or cable box's digital audio output jack

To your VCR's IN and OUT audio jacks

To your TV's audio OUT jacks

To your satellite receiver or cable box's analog audio OUT jacks

To your satellite receiver or cable box's analog video OUT jack

To your VCR's IN and OUT video jacks

To your cassette deck's IN and OUT jacks